

## Proximity Chip Key

Art.-Nr. FUBE50020



- For operating Secvest, Secvest 2WAY and Terxon alarm systems
- Simply hold in front of the alarm or control panel
- Works without contact
- Multiple key fobs can be used with an alarm system
- Several chip keys can be trained

The proximity key is an optional accessory for contact-free switching (arming/disarming) of alarm control panels. Code entry is unnecessary; the user is uniquely authenticated using the proximity key on the alarm system. The proximity key can also be used for opening a door connected with Eycasa.

### Simple operation

The proximity key is used for easy, convenient arming and disarming of the ABUS Secvest 2WAY and Terxon alarm systems or for opening doors provided with and connected to Eycasa. For arming or disarming the alarm control panel, you just hold the chip in front of the panel or control panel – to open doors provided with Eycasa, you hold it in front of the Eycasa door station.

### Installation and programming

The chip key is trained into the alarm panel or Eycasa door system; the authorisation is then programmed directly at the alarm panel or the Eycasa base station. The radio field of the receiver provides the voltage to the proximity key for the code transmission, so that the key does not need its own battery.

### Technical Data

Color	Black
-------	-------

Height	7.5mm
Width	34mm